

INSTALLATION INSTRUCTIONS

FRONT DOUBLE LAYER BULL BAR

13-18 INFINITI JX35

13-19 QX60/PATHFINDER

09-19 NISSAN MURANO

PART # VGFDL-1037-1161SS



Install the brackets as illustrated below (Left to Right, Top to Bottom). For a video guide, visit https://www.youtube.com/watch?v=67Hp_LwZBbk

