

INSTALLATION INSTRUCTIONS

2013-2017 SUBARU XV CROSSTREK

REAR BUMPER GUARD

Hardware	Hardware
Mounting Brackets	Screws (bracket to bar)
T-bolts (bracket to chassis)	Flat Washers (bracket to bar)
Flat Washers (bracket to chassis)	Lock Washers (bracket to bar)
Lock Washers (bracket to chassis)	Nuts (bracket to bar)
Nuts (bracket to chassis)	



STEP 1: Verify all parts are present. Read instructions carefully before starting installation.

STEP 2: Locate the two holes underneath the chassis near the driver's side as shown (Fig. 1)

Fig 1



STEP 3: Place the U-Bolt as shown (Fig. 2)

Fig 2



STEP 4: Mount the bracket (Fig. 3). Add spacers when needed, specially if the thread is lacking.

Fig 3



STEP 5: Put on the flat washer, lock washer and nut. Make sure it is only put on hand tight, as there may be a need for some wiggle room when mounting the bar to the brackets for adjustment.



STEP 6: Do steps 2-5 on the passenger side

STEP 7: With assistance, mount the bar on both brackets using the provided hardware. Take a step back and inspect the bar if adjustments need to be made for alignment. Once content, you can now tighten each piece with a tool.

